## GROUND CONTROL SYSTEMS® Metal Bike Vault® Installation Instructions

## TOOLS NEEDED FOR INSTALLATION

- 1. Safety glasses and ear plugs
- 2. 3/8" Hammer Drill with 3/8" bit
- 3. Hammer
- 4. Torque wrench
- 5. Small vacuum or wire brush

NOTE: These instructions are for installation of bike vaults in CONCRETE ONLY.

CAUTION: Be sure to wear eye and ear protection when drilling holes.


In the Mounting Anchor Kit:

1. Wedge anchors (4):


3/8" X 16-UNC X 3-3/4"


(Includes nut and washer per each)


Quantity depends on which kit





was purchased.












6. Place the washer and nut on the anchor and use a torque wrench to tighten to 30 -33 ftlbs of torque.



For questions or concerns regarding installation using wedge anchors, please call Ground Control at 800-630-7225 or email us at info@groundcontrolsystems.com

These installation instructions are intended for the install of wedge anchors in concrete only. For instructions on installing a bike rack in asphalt, please contact Ground Control or download our asphalt installation instructions from our website.

The information contained in this document is the sole property of Ground Control Systems® any reproduction in part or whole without the written permission of Ground Control Systems® is prohibited.



www.groundcontrolsystems.com info@groundcontrolsystems.com 800-630-7225